

MIPCO

MIDWEST INDUSTRIAL PRODUCTS CORP.

"INDUSTRY LEADER IN EPOXY FLOOR PATCH AND RESURFACERS SINCE 1945"

7424 BESSEMER AVE.
CLEVELAND, OHIO, 44127

M-F 8am-2pm
1-800-521-2107
216-341-8019



Manufactured
in the USA
Since 1945

MIXING INSTRUCTIONS

(Applies to: Fast Rock only)

****ALL INGREDIENTS ARE PREMEASURED**

Step 1: ***REPAIR AREA MUST BE CLEAN AND DRY!**

Step 2: Mix Part A with Part B in the pail supplied for 30 seconds....Then introduce the aggregate and then blend into a homogenous state for approx. 30-45 seconds.

Step 3: Once you reach the desired consistency, apply the product to your project.
Pot life is 5 minutes

Step 4: This is a Trowel-able product. Reminder **Pot life is 5 minutes**

Step 4: Cure times vary per product – refer to product page for individual cure times at mipco.org

WWW.MIPCO.ORG